




Quick Start Guide

FRDM-KW41Z

FREEDOM DEVELOPMENT PLATFORM



Quick Start Guide

GET TO KNOW THE FRDM-KW41Z




Figure 1: FRDM-KW41Z Board Components




Figure 2: FRDM-KW41Z Board Connections

HOW TO GET STARTED

1. Connect the FRDM-KW41Z board to a PC using the included micro-USB cable to the USB OpenSDA connector of the FRDM-KW41Z.
2. Your FRDM-KW41Z RGB LED should start cycling through the colors Red, Green and Blue when you connect the board.
3. Explore more out-of-box demos and download software and tools on **www.nxp.com/FRDM-KW41Z/startnow**.
4. Enjoy your design freedom with the FRDM-KW41Z.



SUPPORT

Visit www.nxp.com/support for a list of phone numbers within your region.

WARRANTY

Visit www.nxp.com/warranty for complete warranty information.



Get Started

Download installation software and documentation under **"Jump Start Your Design"** at www.nxp.com/frdm-kw41z.

www.nxp.com

NXP, the NXP logo and Kinetis are trademarks of NXP B.V. All other product or service names are the property of their respective owners. © 2016 NXP B.V.

Document Number: FRDMKW41ZQRG REV 0

Agile Number: 926-29102 REV A